

Why Point of Care lactate?

January 2012



Brad S. Karon

Director of Point of Care Testing, Mayo Clinic
Department of Laboratory Medicine and Pathology
Mayo Clinic
200 First Street SW
Rochester, MN 55905
USA

Sepsis is a major cause of mortality and morbidity for hospitalized patients around the world. Early intervention can reduce mortality and morbidity from severe sepsis, but signs and symptoms of sepsis are non-specific. Point-of-care lactate has proved to be an invaluable tool for some institutions in standardized protocols for early recognition and intervention in sepsis.

In this article I will explain why performing lactate at the point of care has proved advantageous for some institutions, and elaborate on analytical and preanalytical issues related to lactate measurement.

The problem of recognizing sepsis

Sepsis, or whole-body inflammation accompanied by infection, is common among hospitalized patients. Severe sepsis is defined as acute organ dysfunction secondary to infection [1]. Septic shock is defined as severe sepsis that cannot be resuscitated or stabilized by appropriate IV fluids alone [1].

It has been recognized for decades that patients with severe sepsis and/or septic shock are at high risk of death in the hospital. Early intervention (fluid resuscitation, antibiotics, other treatments) can improve mortality from sepsis. However, the primary symptoms of sepsis (fever or hypothermia, decreased blood pressure, increased heart rate, increased or decreased white blood count) are non-specific and therefore present in a wide variety of patients.

Several years ago it was recognized that all the information was generally available to recognize sepsis early in the hospital setting, but the organization of this information and the ability to act upon it were missing in most institutions. For instance, almost all patients have blood pressure, heart rate and temperature recorded at hospital admission. A great many have a complete blood count and other laboratory work performed shortly after arriving in the hospital or emergency department.

However, rapidly collecting this information and “flagging” patients with potential sepsis or severe

sepsis has proved to be a difficult task. Therefore the Surviving Sepsis Campaign, an international effort to educate healthcare providers about sepsis and help standardize the approach to early recognition of sepsis, was initiated in order to help improve outcomes of hospitalized patients with sepsis [1].

For an excellent review of early sepsis recognition and resuscitation, see the July 2011 edition of acutecaretesting.org [2].

The need for speed

The Surviving Sepsis Campaign, and other published studies on early sepsis intervention, have led to a generally accepted evidence-based pathway for early sepsis resuscitation. The sepsis resuscitation bundle relies upon rapid recognition of sepsis to allow early treatment with fluid support, antibiotics and other interventions shown to reduce mortality. Many institutions have adopted a seven-step sepsis resuscitation (recognition) bundle based upon published evidence:

1. Measurement of serum, plasma or whole-blood lactate before antibiotics
2. Blood cultures drawn before antibiotics administered
3. Antibiotics administered within 1 hour of recognition of sepsis or ICU admission
4. Appropriate fluid resuscitation
5. Vasopressor use where appropriate
6. Red-blood-cell administration where appropriate
7. Inotrope use where appropriate

The first three steps in the resuscitation bundle are laboratory-dependent processes, and it is important to recognize that the rest of the bundle cannot proceed until the laboratory information is either received (lactate) or collected (blood cultures).

Without adding laboratory information (especially lactate, but also white blood count, arterial blood gas parameters if performed), it is extremely difficult to effectively differentiate patients with severe sepsis or septic shock from patients with other conditions. Thus

the laboratory must be a partner in any attempt at a standardized approach to early sepsis recognition.

Sepsis response team at Mayo clinic

Within our institution, Mayo Clinic in Rochester, Minnesota, physicians in the intensive care unit (ICU) study compliance with sepsis resuscitation guidelines described above during three periods of time.

Phase 1: The first time period consisted only of a program to educate ICU physicians and nurses on the signs of sepsis and the steps in the resuscitation bundle.

Phase 2: The second time period consisted of weekly auditing and feedback to physicians and nurses on performance with bundle metrics.

Phase 3: During the third time period a sepsis response team was formed. Members of the response team include physicians, nurses, pharmacists, respiratory therapy and laboratory personnel to draw blood cultures and perform point-of-care lactate testing.

Compliance with the first three elements of the resuscitation bundle (the laboratory-dependent processes, starting with obtaining a lactate value and ending with antibiotics administered within 1 hour) increased from 75 to 85 % during Phase I to 91-97 % during Phase III. Even more importantly, ICU mortality decreased during Phase III compared to either Phase I or II [3].

Feedback from the sepsis response team leaders indicated that point-of-care lactate was essential to both early recognition and intervention in sepsis. Rather than sending a lactate level to the central lab and waiting 20-30 minutes to get a result, the sepsis response team remains at the bedside until lactate values and clinical information are integrated (within minutes of suspecting sepsis) to determine whether to pursue further action.

The ability to differentiate patients who potentially have severe sepsis or septic shock rapidly means that all members of the healthcare team (physicians, nurses, respiratory therapists, pharmacists) are still gathered

at the patient's bedside to initiate prompt intervention with fluids, antibiotics and further care as required. This was not possible before point-of-care lactate testing was initiated, because even a 15-20 minute wait for the lactate value meant that the healthcare providers generally went on to other duties and had to be "recalled" to the patient care situation once the lactate was available.

Compliance with the goals for the laboratory-dependent first three steps of the resuscitation bundle was not possible without point-of-care testing. In addition to point-of-care lactate testing, standardized order sets that nurses can initiate and other steps have allowed earlier and more consistent intervention in sepsis than was possible before the sepsis response team was formed. As with all point-of-care testing, unless protocols or care practices are modified to accommodate the rapid information obtained at point of care, the testing is unlikely to be of significant benefit.

Correlation between point-of-care and laboratory lactate

Within our institution point-of-care lactate plays a critical role in early sepsis recognition and intervention, but how well do whole-blood lactate methods work? We previously conducted a study comparing two whole-blood lactate methods to two different central laboratory methods for plasma lactate, using 90 excess blood gas specimens from the ICU and Emergency Department covering a lactate range of 1-14 mM [4].

The two central laboratory methods were nearly interchangeable. The central laboratory method that was originally validated against ion-exclusion chromatography was chosen as the reference method. The two whole-blood methods correlated closely with the reference central laboratory methods up to lactate levels of 5-6 mM, and at higher levels than that exhibited a negative bias (Fig. 1).




Fig. 1: Bland Altman plot of whole-blood (point-of-care) lactate vs. laboratory lactate. Two whole-blood methods are shown.

In our institution (and many other) the cut-off for initiating the sepsis resuscitation bundle is 4 mM. There were 50 plasma lactate samples with lactate concentrations ≤ 4 mM. All 50 of those "negative" lactate samples were also ≤ 4 mM by both whole-blood lactate methods. There were 40 plasma samples with lactate concentration > 4 mM, a "positive" sample or one that would trigger initiation of the resuscitation bundle. 36/40 (90 %) and 35/40 (88 %) were also > 4 mM by the whole-blood lactate methods.

The small negative bias of whole-blood methods at lower lactate concentrations (Fig. 1) resulted in whole-blood lactate being just under 4 mM for a few patients whose plasma lactate was just over 4 mM. However, overall concordance (percent agreement with laboratory value) around the clinical cut-off of 4 mM used in the sepsis resuscitation bundle was 94 % for one whole-blood method and 96 % for the other whole-blood method. Thus the whole-blood methods worked well for use in the sepsis resuscitation bundle where decision-making is primarily around the cut-off of 4 mM.

Other issues with lactate measurement

Preanalytical issues

Other institutions have reported problems with correlation between point-of-care whole-blood lactate and laboratory plasma lactate. This may be because lactate is sensitive to a number of preanalytical variables

that can result in falsely elevated results. Lactate in whole blood is not stable. Lactate values can increase 1.5-2.0 mM over as little as 15 minutes in a blood gas syringe at room temperature (unpublished data).

When blood gas syringes are placed on ice, the increase was only ~0.2 mM over 45 minutes (unpublished data). Thus personnel performing point-of-care lactate need to be instructed to test whole-blood specimens within 5 minutes of drawing samples or cool samples with an ice slurry. Prolonged tourniquet time or excessive fist clenching during blood draw can also lead to falsely elevated lactate levels. Because patients suspected of sepsis are often difficult to collect blood from, personnel performing these collections need to be aware of the effect of prolonged tourniquet time on lactate levels.

If veins cannot be accessed within 1 minute of applying the tourniquet, the tourniquet should be released and another attempt made rather than keeping the tourniquet on to locate veins or attempt repeated phlebotomies.

Postanalytical issues

One final issue, a postanalytical one, is the reference range used by laboratories for plasma or whole-blood lactate. Textbook or literature reference ranges are sometimes derived from studies of normal volunteers who had blood drawn without a tourniquet to avoid physiologic increases in lactate levels.

Within our institution we conducted a study comparing lactate levels in normal volunteers who had blood drawn with and without the use of a tourniquet. The derived upper limit of the reference value for volunteers drawn with a tourniquet was marginally greater than that for the same volunteers drawn without the use of a tourniquet. However, our laboratory chose to use a combined reference range (using values obtained with and without tourniquet during blood draw) in order to accommodate for the fact that very sick patients (the patients having lactate measured for sepsis recognition) are very difficult to draw without use of a tourniquet.

The combined reference range then accommodates some of the preanalytical issues with lactate collection to allow for better interpretation by clinicians. Laboratories that use an upper limit for the lactate reference range < 2.0 mM should determine whether those values can be consistently obtained under real-life conditions when drawing blood from hospitalized patients who are not septic or have conditions not associated with increased lactate values.

Conclusion

The problem of recognizing sepsis in the hospital, and of early intervention for severe sepsis and septic shock, has been a subject of increasing attention across the world. Early intervention in these patients can reduce mortality, and the information needed should be available but is too often not obtained rapidly enough and/or not collected and organized rapidly enough to initiate effective intervention.

Standardized sepsis resuscitation bundles are one tool that has been shown to reduce mortality from severe sepsis and septic shock. Lactate measurement is the first step in most of these resuscitation bundles. In our institution and others, point-of-care whole-blood lactate methods have proven invaluable in rapid recognition and intervention for severe sepsis and septic shock. Analytical performance of whole-blood lactate methods is suitable for this use, though caregivers should be aware of negative bias in some whole-blood methods at higher (> 6 mM) lactate levels.

Preanalytical errors resulting in falsely high lactate values are probably common, so effective education and training of personnel collecting and testing blood samples for whole-blood lactate are essential.

References

1. Dellinger RP, Levy MM, Carlet JM *et al.* Surviving Sepsis Campaign: international guidelines for management of severe sepsis and septic shock: 2008. *Crit Care Med* 2008; 36(4): 1394-96.
2. Christ M. How to manage sepsis in the emergency department leading to a decreased mortality in ICU – the Critical Care Cascade. www.acutecaretesting.org July 2011.
3. Schramm GE, Kashyap R, Mullon JJ *et al.* Septic shock: A multidisciplinary response team and weekly feedback to clinicians improve the process of care and mortality. *Crit Care Med* 2011; 39: 252-58.
4. Karon BS, Scott R, Burritt MF *et al.* Comparison of lactate values between point-of-care and central laboratory analyzers. *Am J Clin Pathol* 2007; 128(1): 168-71.